

## INSTALLATION GUIDELINES

### Ford EV Pedestal

#### Cable routing/ Pipe Install

1. Lower counterweight as far down as possible.
2. Tip pole on its side
3. Insert the counterweight into the PVC pipe.
4. Slide pipe into the pole until it is flush with the base.
5. Tip the pole upright and follow the routing diagram below to route pulley cable.
6. Rope must make 1 full loop around the aluminum pulley

### Cable Routing Diagram

